

DIFFERENTIAL & TRANSMISSION PARTS - COMMON

NEW STYLE DIFFERENTIAL PARTS

6273

For G&E G16,G19,G20,
G21,G22



Black skid plate

3878

For electric G9 (1993-up)
G14,G16,G19,G22
also gas G16,G20,G21,G22
OEM #93306-007Y0-00/#6007



Carrier bearing both sides

3882

For electric G9 (1993-up)
G14,G16,G19,G22
also gas G16,G20,G21,G22
OEM #93306-303Y6-00/#6303



Intermediate gear
bearing both sides

3854

For electric G9 (1993-up)
G14,G16,G19,G22
also gas G16,G20,G21,G22
OEM #93306-203X1-00/#6203



Input shaft bearing
far side or internal

3872

For electric G9 (1993-up)
G14,G16,G19,G22
also gas G16,G20,G21,G22
OEM #93306-005Y3-00/#6005LL



Input shaft bearing
clutch side or motor side

3131

10/Pkg

For electric G9 (1993-up)
OEM #JH7-H1829-00-00



Spline bumper for G.E. motor

ELECTRIC TRANSMISSION PARTS

3855

For electric G9 (1992-older)
G8,G2,G1
OEM #93306-20421-00/#6204



Input shaft bearing
drive motor side
and counter shaft bearing both sides

3823

For electric G9 (1992-older)
G8,G2,G1
OEM #93306-00803-00/#6008



Output shaft or
carrier bearing both sides

3822

For electric G9 (1992-older)
G8,G2,G1
OEM #93306-20529-00/#6205



Input shaft bearing
far side or inner side

GAS TRANSMISSION PARTS

3822

For gas G1,G2,G8,G9,G11,G14
OEM #93306-20529-00/#6205



Input shaft bearing clutch side

3854

For gas G1,G2,G8,G9,G11,G14
OEM #93306-203X1-00/#6203



Input shaft bearing far side or inside

3855

For gas G1,G2,G8,G9,G11,G14
OEM #93306-20421-00/#6204



Counter shaft bearing both sides

FRONT SUSPENSION - COMMON

HUB & PARTS G2-G22

5057

For G&E G2-G22
OEM #JG5-WF511-10-00



Forged aluminum front hub

5204

For G&E G11 (1996-up) G16,G19,G20,G21,G22
OEM #JN6-F5118-00-00



Rubber coated steel front hub dust cover

3852

Outer bearing

OEM #93306-204X0-00/#6204LL

3872

Inner bearing

OEM #93306-005Y3-00/#6005LL

For G&E G2-G22



Front axle bearings

4645

For G&E G1 (1982-up) G2,G8,G9,G14

OEM #Jn6-25118-00-00



Plastic front hub dust cover

1691

20/Pkg

For G&E all years
OEM #90179-12262-00



12mm zinc plated steel lug nut

6370

For G&E all models
OEM #90114-12806-00-00



12mm lug bolt, front

LOWER FRONT SUSPENSION G22

6366

For G&E G22
OEM #JU0-F3570-20-00



Front lower control arm assembly

6090

Passenger side

OEM #JU0-F3521-01-00

6091

Drivers side

OEM #JU0-F3511-01-00

Shown
#6090

Steering knuckle



5943

For G&E G22
OEM #3JN-23517-00-00



Steering knuckle outer cover

14430

For G&E G22-G29
OEM #90105-10890-00



Bolt for #6366 upper control arm



14414

For G&E G29
OEM #JW1-F3512-00-00



Knuckle arm Passenger and drivers side



5946

For G&E G22-G29
OEM #401-22128-01-00



Front lower arm cover



14411

For G&E G22-G29
OEM #90387-12016-00



Collar



5937

For G&E G22
OEM #90381-18001-00



Lower front control arm bushing

6367

For G&E G22
OEM #JU0-F3512-02-00



Knuckle arm Passenger and drivers side

5938

For G&E G22
OEM #90381-17067-00



Bushing, steering knuckle upper and lower

5934

For G&E G16, G19, G20, G21
OEM #JN6-F3526-10-00



Lower front bushing

FRONT SUSPENSION - COMMON

LOWER FRONT SUSPENSION G2-G20

6084 Passenger side
OEM #JN6-F3580-10-00

6085 Drivers side
OEM #JN6-F3570-10-00
For G&E G2-G19

Shown
#6085



Lower control arm

5456 Passenger side
OEM #JN6-F3521-00-00

5453 Drivers side
OEM #JN6-F3511-00-00
For G&E G2,G8,G9,G14,G16,G19



Steering knuckles

349
For G&E G2,G8,G11,G14,
G16,G19



King pin and bushing kit

271
For G&E G2,G8,G9,G11,G14
G16,G19,G20
OEM #J38-23516-00-00



Metal king pin, 4.62" long

5408
For G&E G14,G16,G19,G20,G21
OEM #JN3-F3512-00-00



Knuckle arm

5409
For G&E G2,G8,G9
OEM #J38-23512-02-00



Knuckle arm

5912
For G&E G2-G20
OEM #95814-10040-00



Knuckle arm bolt to steering knuckle

1647 10/Pkg
For G&E G2-G21
OEM #90201-156J2-00



Steering knuckle washer plate

YAMAHA

FRONT SUSPENSION - COMMON

KING PIN & PARTS G2 - G20

626 For G&E G2-G19 OEM #90338-17225-00  Upper king pin bushing and cap combination	5411 For G&E G2-G19 OEM #90334-19800-00  Upper king pin cap only	5410 Upper OEM #90384-15826-00 5499 Lower OEM #90384-15825-00 For G&E G2-G19  King pin bushing only
625 For G&E G2-G19 OEM #90386-15139-00  Lower king pin bushing	630 For G&E G2-G21 OEM #J38-23527-00-00  Steering knuckle dust seal #1	631 For G&E G2-G19 OEM #J38-23528-00-00  Bottom of king pin dust seal #2
5914 For G&E G2-G21 OEM #95817-10075-00  Lower control arm bolt	5480 For G&E G2-G22 OEM #93102-30083-00  Spindle seal	6368 NEW For G&E G22 OEM #90105-10064-00  King pin bolt

G1 SUSPENSION

5918 For G&E 1982-89 G1 OEM #J17-23510-00-00  Steering knuckle for both sides	270 For G&E G1 OEM #J10-23516-02-00  King pin 5.25" long	5919 For gas G1 OEM #J17-W2355-00-00  Tension rod with bushing
14409 NEW For G&E 1982-up G1 OEM #90381-15032-00  Lower king pin bushing	14410 NEW For G&E 1982- G1 OEM #90381-15040-00  Upper king pin bushing	5920 For gas G1 OEM #J10-23583-01-00  Replacement bushing for tension rod
3852 Outer bearing OEM #93306-20469-00/#6204LL 3872 Inner bearing OEM #93306-00511-00/#6005LL For G&E G1 (1982-up)  Front axle bearings	3871 Outer bearing OEM #93306-20314-00/#6203LL 3870 - Inner bearing OEM #93306-00444-00/#6004LL For G&E G1 (1978-81)  Front axle bearings	1691 20/Pkg For G&E G1 OEM #90179-12262-00  12mm zinc plated steel lug nut 4645 For G&E 1982-95 OEM #J17-25118-00-00  Black plastic hub dust cover

REAR SUSPENSION - COMMON

REAR AXLES



5901 Passenger side rear axle
23-1/4" long OEM #JR1-G6512-00-00

5900 Drivers side rear axle
18-1/2" long OEM #JR1-G6511-00-00

Above axles for electric G16,G19,G22

5903 Passenger side rear axle
18-1/4" long OEM #JN3-G6512-00-00

5902 Drivers side rear axle
23-1/2" long OEM #JN3-G6511-00-00

Above axles for gas G14,G16,G22

5905 Passenger side rear axle
22-5/8" long OEM #JF3-G6512-01-00

5904 Drivers side rear axle
19-3/16" long OEM #JF3-G6511-01-00

Above axles for electric G14,G16

4265

For G&E G8,G9 (1992-up)
G14,G16,G19,G20, G21,G22
OEM #JN3-G6514-00-00



Rear hub

4261

For G&E G1-G22
OEM #J55-G5621-00-00



Brake drum

3936

For G&E 1995-up G14-G22
OEM #93101-24822-00



Oil seal

6376

For G&E all years
OEM #90114-12004-00



12mm lug bolt, rear

14470

For G&E G14-G22
OEM #93420-44805-00



Bearing retaining ring

YAMAHA

SHOCK ABSORBERS - COMMON

FRONT SHOCKS - GAS & ELECTRIC

14526

Drivers side

OEM #JW1-F3350-00-00


14527

Passenger side

OEM #JW1-F3390-00-00

For G&E G29

Front shocks



Shown
#14526



FRONT SHOCKS - GAS & ELECTRIC

6088

Drivers side

OEM #JU0-F3350-20-00

6089

Passenger side

OEM #JU0-F3390-20-00

For G&E G22

Front shocks



Shown
#6088

FRONT SHOCK ASSEMBLIES - ELECTRIC

5413

For electric G14,G16,G19

OEM #JN4-F3350-00-00

5414

For electric G2,G9

OEM #JH7-F3350-00-00

Shown
#5413



FRONT SHOCK ASSEMBLIES - GAS

10913

For gas G20,G21

OEM #JN4-F3350-00-00

5412

For gas G14,G16

OEM #JN3-F3350-00-00

10899

For gas G2,G9

OEM #JN6-F3841-00-00

9078

For gas 1978-89 G1

OEM #J42-23350-00-00

Shown
#5412



SHOCK ABSORBER NUTS

14458

For G&E G14-G29

OEM #95607-10200-00

3/8" shock absorber nut



SHOCK ABSORBERS - COMMON**REAR SHOCK - GAS & ELECTRIC****14529**For G&E G29
OEM #JW1-F2210-00-00**NEW**

Rear shock

REAR SHOCK ASSEMBLIES - ELECTRIC**10897**For G&E G14,G16,G19,G22
OEM #JN4-F2210-00-00**9307**

Heavy duty

For G&E 1995-up G14-G22
OEM #JJ3-F2210-10-00**5417**For electric G2,G9
OEM #JG6-F2210-00-00Shown
#9307**REAR SHOCK ASSEMBLIES - GAS****5416**For G&E G14,G16,G19,G22
OEM #JN4-F2210-00-00**9307**

Heavy duty

For G&E 1995-up G14-G22
OEM #JJ3-F2210-10-00**10830**For gas G2,G9
OEM #JG5-F2210-00-00**9082**For gas 1978-89 G1
OEM #J10-22210-00-00Shown
#5416**HEAVY DUTY REAR SPRINGS****6280**

For G&E G8,G14,G16,G19,G20,G22

Beefed up rear suspension/shock springs.
Now there is something for your Yamaha suspension**SHOCK ABSORBER NUTS****14458**For G&E G14-G29
OEM #95607-10200-00**NEW**

3/8" shock absorber nut

STEERING PARTS - COMMON

UPPER STEERING PARTS

6372

For G&E G14-G22
OEM #JN3-F3838-00-00



Steering wheel

6373

For G&E G14-G22
OEM #JN6-K8358-01-00



Scorecard holder

6883

For G&E 2007 Drive also G9,G14,G16,G22
OEM #JN3-K8357-00-00



Scorecard

14292

For G&E G8-G22
OEM #JN3-K7762-01-00



Warning label decal

OPERATING INSTRUCTIONS

- Read the warning label on the beverage holder panel before operating.
- Be sure occupants are seated.
- Select "FORWARD" or "REVERSE" then turn motor switch to "ON".
- Press the accelerator pedal to start moving. The motor will start and the parking brake will release automatically.
- To stop, release the accelerator pedal and press the brake pedal.
- Never travel at speeds too fast for the terrain, visibility conditions, or your experience.
- Drive with extra caution in congested areas, when operating in reverse, and when driving on wet, rough, or loose surfaces.
- Come to a complete stop before reversing direction.
- Press the parking brake pedal until it locks, and turn the main switch to "OFF" before leaving the vehicle.
- Read the Owner's/Operator's Manual for more information.



ATTENTION

- This vehicle was not manufactured for use on public streets and does not comply with Federal motor vehicle safety standards applicable to passenger cars.

13048


For G&E G22,G29
OEM #JU0-F3828-00-00



Steering shaft

6371

For G&E G1-G21
OEM #J10-23840-00-00



Steering shaft

13025

For G&E G9-G19
OEM #JG5-F3811-00-00



Steering column

13041

For G&E G9-G19
OEM #JN3-F3814-00-00



Upper steering column bushing

3988


For G&E G1 only
OEM #93104-15005-00



Top steering shaft oil seal

3860

For G&E G1-G21
OEM #93332-00010-00/#30203




Steering shaft middle and bottom bearing

3947

For G&E G1 1982-88,
G2 1985-89
OEM #93102-22087-00

3989


For G&E G1 (1978-81)
OEM #93101-22067-00




Pitman arm oil seal

STEERING PARTS - COMMON

LOWER STEERING PARTS - G29

13026For G&E G29
OEM #JW1-F3400-00-00**NEW**


Steering box assembly

13057For G&E G29
OEM #JW1-F387E-00-00**NEW**

Steering rack

13055For G&E G29
OEM #JW1-F3837-00-00**NEW**


Steering rack end

13037For G&E G29
OEM #5UG-F3527-00-00**NEW**

Steering rack bellows

13056For G&E G29
OEM #JW1-F387A-00-00**NEW**

Steering pinion gear

13054For G&E G29
OEM #JW1-F3812-00-00**NEW**

Steering pinion bearing

13038For G&E G29
OEM #5UG-F3844-00-00**NEW**

Steering pinion seal

STEERING PARTS - COMMON

LOWER STEERING PARTS

6848

For G&E 2001-06 G22
OEM #JU0-F3400-00-00



Steering box assembly

9393

For G&E 2003-up G22
OEM #JU0-F387E-00-00



Steering rack

13050

For G&E G22
OEM #JU0-F387A-00-00



Steering pinion gear

13045

For G&E G22
OEM #JU0-F339Y-00-00



Steering pinion bearing

13049

For G&E G22
OEM #JU0-F3844-00-00



Steering pinion seal

13047

For G&E G22
OEM #JU0-F3822-00-00



Steering joint

10889

Right thread

OEM #JN6-F3841-00-00

10888

Left thread

OEM #JN6-F3845-00-00

For G&E G16,G19,G20,G21



Tie rod ends

13042

Drivers side

OEM #JN6-F3830-11-00

13043

Passenger side

OEM #JN6-F3850-10-00

For G&E G9-G19



Tie rod assemblies

9394

Inner

OEM #JU0-F3837-00-00


9395

Outer

OEM #JU0-F3841-00-00

For G&E 2003-up G22

Shown Below
#9394



Inner and outer tie rods

6077

For G&E G9,G14,G16,G19

OEM #J38-23816-00-00



Pitman arm

255

Right thread

OEM #J38-23841-01-00

256

Left thread

OEM #J38-23845-0100

For G&E G2,G8,G9,G11,G14



Tie rod ends

253

Right thread


OEM #J10-23841-10-00

254

Left thread

OEM #J10-23845-10-00

For G&E G1



Tie rod ends

6078

For G&E G9, G14, G16 & G19

OEM #J38-23826-01-00




Idler arm

9363

For G&E 2003-up G22

OEM #JU0-F3848-00-00



Steering rack bellows

STOP SWITCHES - COMMON

STOP SWITCHES

5494

For G&E G14-G22
OEM #JF7-82817-20-00



Stop switch assembly

9199

For G&E 1985-94 G2-G9
OEM #J41-82550-02-00



Stop switch assembly

2647

For gas (2 cycle) G1
OEM #J17-82550-01-00



Stop switch assembly